

ROGAUGE 24.06 Gauge Bar

For adjusting or maintaining a defined gauge.

ROGAUGE Iso

- **Insulated**
- Can be fitted simply and easily to the foot of the rail
- For rails with a base width of 125 mm to 150 mm (e.g. 49E1/54E3 and 60E1)

ROGAUGE Iso Flat

- **Insulated**
- For slab track (spacing concrete-rail > 35 mm) and for ballasted track
- For rails with a base width up to 160 mm

ROGAUGE Iso Switch

- **Insulated**
- Cropped design perfect for use in switches
- No danger of tripping due to design
- Can be fitted simply and easily to the foot of the rail
- Can also be used on open track

ROGAUGE

- **Not insulated**
- Mounted to the grooved plates (K; KS track)
- Adjustment via threaded spindle when installed

Adjustment via threaded spindle when installed.
Different gauges available on request.



ROSHOE 24.08 Rail Pulling Shoe

For pulling rails in the ballast.

- For various types of rail up to a rail length of 180 m, depending on the condition of the track
- Can be used for drilled and undrilled rails
- Does not cause impressions or deformations of the rail

Rail profiles on request.



SPECIFICATION

Dimensions (L x W x H)	455 x 216 x 280 mm
Weight	approx. 39 kg